### **Motion Control**

For current pricing, please see our website.

## CHAPTERS

Manual Stages
Motorized Stages
Multi-Axis Platforms
Actuators

### Controllers

VS	ECT	0	NS
V S			10

Stepper Motor
DC Servo
Rack System Overview
Benchtop Overview
T-Cube Overview

Stepper Motor
Piezo/Strain Gauge
Auto-Alignment
Solenoid
apt Control Software
Tutorials

# The contraction of the contracti

Compact Housing

The TDC001 T-Cube<sup>™</sup> USB DC Servo Motor Driver is a compact, single-channel controller for easy manual and automatic control of DC servo motors. This driver has been designed to operate with a variety of low-powered, DC-brushed motors (up to 15 V/2.5 W operation) equipped with encoder feedback. The TDC001 has been optimized for out-of-the-box operation with Thorlabs' range of Z8 DC motor-equipped optomechanical products (see page 608). The highly flexible software settings and closed-loop tuning also support operation with a wide range of third-party DC servo motors and associated stages and actuators.

USB connectivity provides easy plug-and-play, PC-controlled operation. The TDC001 also includes the user-friendly apt<sup>TM</sup> software, which allows the user to quickly set up complex moving sequences. For example, all relevant operating parameters are set automatically by the software for Thorlabs' stage and actuator products. Advanced custom motion control applications and sequences are also possible using the extensive ActiveX<sup>®</sup> programming environment.

For added convenience, multiple units can be connected to a single PC via standard USB hub technology or by using the T-Cube<sup>TM</sup> Controller Hub (TCH002) for multi-axis motion control applications (see pages 620 - 621 for further details).



### Features

T-Cube<sup>™</sup> Brushed DC Servo Motor Controller (Page 1 of 2)

- USB Plug-and-Play Allows Easy Multi-Axis Expansion
- Full apt<sup>TM</sup> Software Control Suite Supplied
- Differential Encoder Feedback for Closed-Loop Positioning
- Auto-Configure Function for all Thorlabs Z8 DC Servo Motors
- Easy-to-Use Manual Controls with Velocity Slider and Jog Buttons
- Extensive ActiveX<sup>®</sup> Programming Interfaces
- Fully Software Integrated with Other apt<sup>TM</sup> Family Controllers

### Specifications

- Motor Drive Connector (15-Way D-Type):
  - Motor +15 V and -15 V Drive Outputs
  - Quadrature Encoder (QEP) Input (Single Ended)
  - Forward, Reverse Limit Switch Inputs (+ Common Return)
  - 5 V Encoder Supply
- Front Panel Controls:
  - Potentiometer Slider: 4-Speed Bidirectional Velocity Control
  - Dual Buttons: Forward/Reverse Jogging or Position Presets
- Motor Drive Voltage: ±10 V to ±12 V Depending on Supply
- Motor Drive Current: 150 mA (Cont), >250 mA (peak)
- Motor Drive Type: 8-Bit Sign/Magnitude PWM
- Control Algorithm: Digital PID Filter (16-bit)
- Position Feedback: Quadrature Encoder (QEP) Input, 5 V Single Ended
- Encoder Feedback Bandwidth: 750 kHz
- Position Counter: 32-bit
- Operating Modes: Position, Velocity
- Velocity Profile: Trapezoidal
- Input Power Requirements: 15 V Regulated DC, 500 mA (Peak)
- Dimensions (W x D x H): 2.36" x 2.36" x 1.87" (60.0 mm x 60.0 mm x 47.5 mm)
- Weight: 5.5 oz (160 g)

### **Compatible Motor Specifications**

- Motor Type: Brushed DC Servo
- Drive Voltage (Max): 12 V
- Peak Power: 2.5 W
- **Rated Current (Nominal):** 10 200 mA
- Coil Resistance (Nominal): 5 50 Ω
- Coil Inductance: 250 1500 µH
- Position Control: Incremental Encoder
- Resolution: Encoder Specific

# **T-Cube™ Brushed DC Servo Motor Controller (Page 2 of 2)**

The TDC001 DC Servo Controller easily connects to one of our Z8 DC motor actuators. Motor operations are then controlled by the potentiometer slider and jog buttons located on the top face of the unit. Using the top panel slider, the motor can be driven at predefined speeds in either forward or reverse directions for velocity control. Similarly, the jog buttons can be used to make discrete position increments in either direction enabling precise and repeatable positioning. For full flexibility, the supplied PC software can be used to fully control the TDC001 and alter both the speed response of the slider and the jogging modes for the buttons – saving any changes to the memory within the driver unit allowing the PC to be disconnected once changes have been made.


### **TDC001 DC Servo Driver Applications**

The TDC001 DC Servo Driver T-Cube<sup>TM</sup> can be used to control our complete range of DC motor-driven, optomechanical products, such as the MT1-Z8 and MT3-Z8 translation stage and the PRM1Z8 rotation stages. For 3-axis control, three DC Driver T-cubes can be used, either on the TCH002 controller hub (see pages 620 – 621) or bolted directly to the optical table.

### **Power Supply Options**

Recommended Power Supply	
TPS001 or TPS008	
TCH002	
	TPS001 or TPS008

The TCH002 USB Controller Hub (see pages 620 - 621) provides power for up to six T-Cubes. Furthermore, the controller hub contains a fully USB20 compliant hub to provide communications for up to six T-Cubes with a single USB connector to the controller hub.



ITEM #	\$	£	€	RMB	DESCRIPTION
TDC001	\$ 595.00	£ 428.40	€ 517,65	¥ 4,742.15	T-Cube™ Single Channel USB DC Servo Controller/Driver
TPS001	\$ 25.00	£ 18.00	€ 21,75	¥ 199.25	15 V Power Supply Unit for a Single T-Cube
TPS008	\$ 175.00	£ 126.00	€ 152,25	¥ 1,394.75	15 V Power Supply Unit for up to 8 T-Cubes
TCH002	\$ 726.90	£ 523.37	€ 632,40	¥ 5,793.39	T-Cube™ Controller Hub and Power Supply Unit

# Have you seen our...





- ◆ 6, 12, or 25 mm of Travel
- Maximum Speed of 3 mm/s

Compact 12 VDC Servo Motor

Our Z8 Series of Motorized Actuators are designed specifically for use with optical positioning devices such as mirror mounts and stages. With two barrels options, the Z8 motors can be used to replace manual actuators when the need to automate one or more axes arises.

# **Motion Control**

M

CHAPTERS V

V. I
Manual Stages
otorized Stages
Multi-Axis Platforms
Actuators
Controllers
SECTIONS V
T-Cube Overview

Rack System Overview DC Servo Stepper Motor Piezo/Strain

Benchtop

**Overview** 

Auto-Alignment

```
Solenoid
```

Gauge

apt Control Software

Tutorials